

MANUAL COMANDOS QT500 TRACKER TK116 TK119



Plataforma de Rastreo GPS

¿Aún no tienes tu propia plataforma?

Si aún no tienes tu propia plataforma de monitoreo, consulta con nosotros sobre cómo puedes montar tu propio sistema. info@celcominter.com Skype: celcomtrack

COMANDOS FRECUENTES.....

IP 0000 71.6.165.202 65241 (conf. IP)

APN 0000 MOVISTAR.PE (conf. apn)

AT 0000 60 (tiempo) = 1 MINUTO (120 = 2 MINUTOS)

STATUS 000 (coordenadas)

Pánico/audio:

MANAGER 0000 1 99999999 en vez de poner 9999..... poner el número de celular al que debe llegar alerta

Solicitar coordenadas : LOC 0000

Apagado : Relay 0000 1

1. Set the IMEI

IMEI PASSWORD IMEI

2. Set the password

PASSWORD CURRENTPASSWORD NEWPASSWORD

3. Set the server address

IP PASSWORD DOMAINorIP PORT NUMBER

4. Set time zone

TZ PASSWORD TIMEZONE

5. Set managers numbers

MANAGER PASSWORD MANAGERID MANAGERNUMBER

6. Get ID

MYSELF

7. Get the version

VERSION PASSWORD

8. Get settings

CONFIG PASSWORD

9. Get hardware status

STATUS PASSWORD

10. Position Inquiry

POS PASSWORD

11. Monitor

LISTEN PASSWORD PHONE NUMBERS